



Oscilloscope

Quick Guide

Set Up:

1. Turn on using power button on top.
2. Make sure a probe is plugged into the channel you intend.

Use:

1. Attach the black probe to the ground (negative terminal) of your circuit.
2. Clip on the grey probe to the location on the circuit where you want to measure the signal.
- 3a. Click the AUTO button to automatically adjust vertical (voltage) and horizontal (time) scale.
- 3b. OR manually adjust with knobs.

To display information such as frequency, period, or V_{max} , click on "Measure", then use the blue buttons and upper lefthand dial to navigate. Press on the dial to select a field.

Clean Up:

1. Unclip the probes from the circuit and turn off the oscilloscope.
2. Place the probes in the container below.

Want more information?

>Link to Video Playlist<

>Link to Oscilloscope Manual<